

## **MYA FREE SAILING 36", MARBLEHEAD & A CLASSES**

## BOAT, RIG and SAIL SUPPLEMENTARY CERTIFICATION CONTROL FORM

(this is not a certificate)

Hul	l Registrat	ion Number					
<ul> <li>NB MEASURERS</li> <li>1 Certification control shall be carried out in accordance with the Equipment Rules of Sailing except where varied in the class rules.</li> </ul>							
MARBLEHEAD							
HULL							
1	D.2.4 and 4.3.1	Except that the axis of the main spindle of a vane steering gear sh be inboard the <b>hull</b> and any other part of a vane steering gear ma project outboard the <b>hull</b> , is the length of the <b>hull</b> , in relation to the datum waterplane described in figure J.2, minimum 1275 mm and maximum 1290 mm?	y e				
SPINNAKER POLE							
2	4.4.3	Does the largest distance from the face of the <b>mast</b> (without <b>fittin</b> and <b>rigging</b> ) to the attachment point of the <b>spinnaker tack</b> to the <b>spinnaker pole</b> exceed 375 mm?					
3	4.4.4	Is the <b>spinnaker pole</b> without <b>fittings</b> or <b>rigging</b> capable of fitting within a cylinder of 20 mm internal diameter? See Note 1	yes / no				
A CLASS							
BOAT							
4	H.2.1 (c)	A 200 gram weight is used instead of a 100 gram weight?	yes / no				
SPINNAKER POLE							
5	5.5.6	Does the largest distance from the face of the <b>mast</b> (without <b>fittin</b> and <b>rigging</b> ), to the attachment point of the <b>spinnaker tack</b> to the <b>spinnaker pole</b> exceed the J measurement?					
6	5.5.7	Is the <b>spinnaker pole</b> (without <b>fittings</b> and <b>rigging</b> ) capable of pathrough a 25 mm internal diameter ring gauge? See Note 1	assing yes / no				

Note 1

It is unlikely it will be possible to test this without having a cylindrical tube of the prescribed internal diameter and removal of the **fittings** and **rigging** from the **spinnaker pole**. However, a ring gauge of appropriate internal diameter can be applied easily to test the cross section of the **spinnaker pole** without **fittings** and **rigging**. A straight edge can be used to test the curvature of the **spinnaker pole** without **fittings** and **rigging**. Where it seems likely the combination of curvature and cross section will mean the **spinnaker pole** without **fittings** and **rigging** and **rigging** and **rigging** would not fit the prescribed cylinder, the owner should remove the **fittings** and **rigging** and a suitable cylinder used to test compliance.

## **DECLARATION BY THE MEASURER**

I confirm that I have taken the measurements on the rig/sail supplementary **certification control** form, that the particulars on this form are correct and that, to the best of my knowledge, the **hull**, **appendages**, **rigs**, **rigging**, **fittings** and **sails** comply with Sections D, E, F and G of the **class rules** of the appropriate **class** in force at present, except as I have stated below.

If the **official measurer** has any doubt concerning the application of, or compliance of any part of the **boat** with, the **class rules** he shall report it on the **certification control** form(s) before sending them to the **certification authority** and not sign the **certification control** form(s) or **sails**.

Name of Measurer (BLOCK CAPITALS) Officially recognised by (World Sailing Member National Authority of Country)


Signature

Date

.....

RULES THAT APPLY AT AN EVENT

The following rules are rules that are not checked as part of the **certification** process. Like all Section C **class rules** they apply at an event and are subject to **equipment inspection**. They are listed here as an aid to **equipment inspectors**.

Class R 36", M and A		ule Hull Registration Number					
1	2.5.1	Are spinnakers of <b>soft sail</b> construction?	yes / no				
2	2.5.2	Is more than one <b>spinnaker</b> used at a time?	yes / no				
3	2.5.4	Does the <b>spinnaker</b> have more than three attachment points?	yes / no				
4	2.5.7	Is more than one <b>spinnaker pole</b> used?	yes / no				
5	2.5.6	Except at the <b>head</b> , is there any other <b>stiffening</b> ?	yes / no				
6	2.5.8	Is a <b>spinnaker</b> sheeted to any <b>boom</b> ?	yes / no				
7	2.5.9	Is a spinnaker tack attached more than 25 mm from the end of the <b>spinnaker pole</b> measured along the pole?	yes / no				
Marblehead SPINNAKERS							
8	4.4.1	Does the top width exceed 30 mm?	yes / no				
9	4.4.2	Does the attachment point of the <b>spinnaker head</b> to the <b>mast</b> exceed 1728 mm above the deck <b>limit mark</b> ?	yes / no				
A Class							
5PI 10	NNAKEF 5.5.1	Does any <b>stiffening</b> at the <b>head</b> exceed 30 mm height or width?	yes / no				
11	5.5.4	Does any luff length or leech length exceed the I dimension?	yes / no				
12	5.5.5	Does any <b>foot length</b> , <b>quarter width</b> , <b>half width</b> , or <b>three quarter width</b> exceed the 2J + 152 mm measurement?	yes / no				
13	5.5.3	Is the attachment point of the <b>spinnaker head</b> or its <b>halyard</b> to the <b>mast</b> aft of a straight line between the foretriangle height limit mark and the foretriangle deck limit mark?	yes / no				
14	C.8.4 (b)(4)	Does the <b>headsail clew point</b> extend aft of the <b>mast</b> (without <b>fittings</b> and <b>rigging</b> )?					
15	5.5.8	When <b>equipment inspection</b> is carried out, <b>spinnakers</b> and <b>sails</b> that will be used as <b>spinnakers</b> are marked at the <b>head</b> with the smallest J dimension with which the <b>sail</b> complies?	yes / no				

end